

Important Notice

The gas bottle on/off tap must be switched (clockwise) off before disconnecting the gas regulator.

Only open the gas bottle valve (turning anti-clockwise) after the regulator instructions below have been read and understood.

To avoid any accidents or fire issues, do not leave the gas bottles switch on after use. Close the gas off by turning the gas knob in the clockwise position. Persons disconnecting the gas regulators should have read the instruction below before disconnecting. Do not smoke or disconnect near any sources of ignition, heaters, sparks, smoke or vape within the vicinity.



Hand tighten anti clockwise to compress the black rubber doughnut. Gas is low pressure tighten by hand only, do **not** use grips. Do not allow the pipe or pipe fixing to kink or rotate. If you can smell gas after tightening switch of the gas bottle, leave the area for 5 minutes and re-check the connections.



Brass POL connector screw up by hand anti clockwise, final tighten with spanner (FT) fully tight. Do not allow the pipe or pipe fixing to kink or rotate. If you can smell gas after tightening switch of the gas bottle, leave the area for 5 minutes and re-check the connections.



Adjustable Cinders BBQ brass POL connector screw up by hand anti clockwise, final tighten with spanner (FT) fully tight. Do not allow the pipe or pipe fixing to kink or rotate. If you can smell gas after tightening switch of the gas bottle, leave the area for 5 minutes and re-check the connections.