

Operation

1. Connect the appliance to the mains power supply.
2. Fill the outer container with approximately 600ml of water.
3. Carefully place the inner container into the appliance.



Note: The inner container must NOT float, even when empty. If the container floats reduce the amount of water in the outer container.

4. Fill the inner container with hot soup and close the lid.



Note: If necessary, remove any excess water from the outer container.

5. Set the temperature control. The temperature ranges from 1 (lowest) to 12 (highest).
6. The Power light will come on and the kettle will begin to heat up.



Note: Kettle is not designed to heat food from cold.

7. Reduce the temperature to maintain heat levels. To maintain temperature, BUFFALO recommend the lowest heat setting possible.
8. Use a suitable implement to remove the contents of the kettle. DO NOT tip the kettle to remove the contents.
9. To turn the appliance Off, set the Temperature Control to '0'.



WARNING: Never move or carry the appliance when it is switched on or contains hot liquid.