

SAFETY PRECAUTIONS

READ ALL THE INSTRUCTIONS CAREFULLY BEFORE USING YOUR DUALIT BLENDER. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE REFERENCE.

Always follow these safety precautions when using your blender for your own safety and to avoid damaging the appliance.

- To protect against risk of electrical shock, do not submerge the motor housing, cord or plug in water or any other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors.
- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to these instructions the guarantee becomes invalid and Dualit refuses any liability for damage caused.
- Never tamper with the safety systems. They are included for your personal safety.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not let cord hang over edge of table or counter.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running and jar is off the base.
- Blades are sharp. Handle carefully.
- To reduce the risk of injury never place the blades on the base without jug properly attached.
- Always operate blender with lid in place, the jar may leak if the lid is damaged or incorrectly fitted.
- Do not lift the jar up while the motor is running.
- Avoid contact with moving parts, never reach into the jar with your fingers or an object (e.g. a spatula) while the blender is running.
- **This is an attended appliance.**
- Children should be supervised to ensure that they do not play with the appliance.
- The use of attachments, not recommended or sold by the manufacturer may cause fire, electric shock or injury.

SAFETY PRECAUTIONS








- Do not attempt to defeat the interlock mechanisms.
- Be certain the jar is firmly on the base and the lid and blade assembly is correctly in position before operating appliance.
- Never blend more than 2.0 litres or 1L when crushing ice.
- Keep jug empty when not in use.
- Caution, after extended periods of use the metal drive coupling on the blade assembly may become hot.
- If the blade is jammed, switch off and unplug the blender before removing the lid.
- Do not blend dough, pastry or mashed potato.
- When blending heavy loads pulse for 30 seconds and allow cooling until room temperature between each pulse. Please note that no recipe contained within the manual is considered a heavy load.
- Do not operate the blender empty.
- Make sure the electrical outlet is rated at the same voltage as that stated on the bottom of the power base.
- Use this product with rated voltage A.C. outlet only.
- Be sure to unplug the A.C. cord when blender is not being used.

WHEN BLENDING WARM ITEMS

- When blending warm items do not blend over 1L and only use setting 1.
- When processing warm liquids, always place a hand with heatproof glove on the lid when blending, loosely cover so steam can escape.
- Do not add boiling liquids or foods to the jar. Always cool liquids or food items to below 60°C before adding to the jar and do not fill above 1L.
- Frozen foods with the exception of small pieces of fruit or ice cubes should not be placed in the jug.
- Do not insert frozen items into jug taken directly from a hot dishwasher.
- Do not immerse or wash jug in boiling or very hot water.
- Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
- Do not plug the appliance in before checking that the voltage indicated on the rating plate is the same as the electrical supply voltage.
- If the power cord is damaged it must, for safety reasons, be replaced by Dualit or an authorised Dualit repairer.
- Do not operate the blender with a damaged cord or plug or after appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest Authorized Service Centre for examination, repair or electrical or mechanical adjustment.

SETTINGS & THEIR USES

This chart is only to be used as a guide. Auto Pulse is suitable for most ingredients, use this setting first then use the other settings as required.

SETTING	FOOD	BLENDING TIME
	Thick smoothies Any tough ingredients (below 60°C)	Press once Press once
	Chopping nuts / onions Additional pulses after auto pulsing	As required 2 - 6 pulses
	Fine crushed ice / iced snow Chopped ice (press stop after 2-3 pulses)	Press once Press & stop
	Warm soups (below 60°C) Coarse chopping	10 - 30 secs 10 - 20 secs
	Thin fruit drinks Batters	20 -30 secs 20 / 20 secs*
	Ice based fruit drink Lean meats	10 - 15 secs 20 / 20 secs*
	Purees / baby food Sauces (thick)	10 - 15 secs 20 / 20 secs*

NB: Times are a guide and may vary depending on volumes and ingredient types.

* After 20 seconds turn off the blender, stir the ingredients, and then continue blending.

BLENDING WARM LIQUIDS

**CAUTION: DO NOT BLEND HOT OR BOILING LIQUIDS.
ALWAYS COOL TO BELOW 60°C AND BLEND ONLY 1L AT A TIME.**

Allow hot items to cool below 60°C before blending.

Do not fill above the 1L mark to avoid spillages.

Place a hand wearing a heat proof glove on the lid. Do not fully cover the filler hole, to allow the steam to escape.

Use speed 1 for blending warm items.

Do not use Auto Pulse function when blending warm liquids.

NOTES FOR BLENDING

ALWAYS PLACE ONE HAND ON TOP OF THE LID WHEN THE MOTOR IS RUNNING. DO NOT SHAKE OR LIFT THE JAR WHILST BLENDING

1 REDISTRIBUTING

STOP AND REMOVE THE JAR OFF THE BASE. Use a spatula to redistribute the ingredients. Never use metal utensils, as you may damage the jar or blade.

2 ADDING

Add additional ingredients in to the blender through the filler cap aperture. Do not do this when blending warm items.

3 DO NOT SHAKE OR LIFT

Whilst blending do not shake or lift off the jar. If the motor is running this will permanently damage the drive coupling.

DO'S & DON'TS

Here's a few simple rules to help you get the most out of your blender.

Do's	Don'ts
1. Add liquid items in the jar first then add solid food items on top.	1. Do not use the blender jar to store food and do not store jar in the fridge.
2. Use a combination of blend settings and Auto Pulse to suit the items being blended. Auto Pulse is ideal for solid items, chopping nuts and for smoothies.	2. Do not over process, the blender works fast and most food will blend in seconds.
3. Redistribute the items in the jar as required. When blending, thick mixtures may stick to the side of the jar. Always turn off and unplug before redistributing.	3. Do not use with dough, mashed potato or glutinous mixtures.
4. Cut ingredients into evenly sized 2cm chunks for a more consistent blend.	4. Do not shake or remove the jar while the blender is operating. Always turn off the main power, unplug and wait for the blades to fully stop before taking the jar off the base.
5. Take extra caution when handling and storing the blades.	5. Do not overfill the jar as this may cause the jar to leak or stall the motor.
6. Hold the lid down with one hand (gloved if blending warm items) whilst blending.	6. Do not blend hot or boiling items, allow to cool below 60°C before adding to the jar & do not blend over 1L at a time. Use speed setting 1 and do not use Auto Pulse function.
7. Blend ice immediately once added to the jar.	7. Do not fill above the 2.0L.
	8. Never run the blender empty.