

---


## Operations Information

### Fresh Water Delivery System

The plumbing system in this sink is simple and requires minimal maintenance. If the system becomes plugged, check the foot pumps first. Depress each foot pump and observe the level of resistance. If there is resistance and no water is dispensed, there is most likely an obstruction in the tube or at the orifice of the water spigot. If there is no resistance and no water is dispensed, then either a.) a tube connection is loose or b.) an internal rubber part of the pump needs replacing.

### Filling with Fresh Water

To open the hinged top you must first remove the top of the trash chute on both sides. Then release the latch locks. Insert a standard 1" garden or similar type hose into the 1-1/4" round fill port under the lid. Fill the sink with a few gallons of fresh water to perform a system check. Depress both foot pumps a few times to "prime" them. The pumps have built in check valves that will hold a prime between uses. The sink is equipped with "weep" holes located at the top of the recessed handles in the sides. Once the tank has reached capacity, fresh water will "weep" from these holes.



### Emptying Fresh Water

At the bottom left center of the sink, there is a drain port.

### Emptying Gray Water

Certain geographical areas prohibit "dumping" of gray water and require it be properly disposed of. The gray water can be pumped out by lifting the hinged top. There is also a drain port located at the bottom right center of the sink.